


Robot AZ & ZN controller on the CE-9206
(small e-card fixed to the control box lid)



● If the instrument is showing strange internal voltage, *example !!! or higher than normal readings* check these IC multiplexers by switching them. If internal voltage show normal after switching, replace both.

● RAM

● EPROM

